

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com



# **Using You Set-up Instructions:**

The Visionary Designs Set-up Instructions for Sacagawea displays are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display and a logical series of detailed steps for assembly. We encourage you to study the instructions **before** attempting to assemble your exhibit.

### THIS IS VERY IMPORTANT!

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in red).

# **Cleaning & Packing Your Display:**

- 1) Use care when cleaning aluminum extrusions or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or counter tops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing materials. It will make re-packing much easier and will reduce the likelihood of shipping damage.

Hex Key Tool




Most visionary design exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.


**Typical Connection** 



Detail A: Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.



Detail B: Each extrusion contains a numbered label that corresponds to set-up instructions. The label is located within a groove of the extrusion (when possible). Visionary Design labels contain Black numbers unless otherwise specified. Horizontal Connection



Detail C: A rectangular connection bar with plastic T Knobs is inserted between two horizontal extrusions joined end-to-end. Turn the knobs clockwise to tighten.

Do Not Overtighten.

**Base Plate Connection** 

Detail D: Attach vertical extrusions to base plates with supplied bolts inserted through the hole in the plate. Be careful not to strip the thread.

Vertical Connection



Detail E: A square connection bar with plastic T Knobs is inserted between two vertical extrusions joined end-to-end. Turn the knobs clockwise to tighten.

Do Not Overtighten.

# WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

# **Typical Connection**



#### Corner Connection




Detail F: Plastic Star Knobs are used to tighten locks where horizontal extrusions connect with vertical extrusions. Turn the knobs clockwise to tighten. Turn counterclockwise to loosen, but do not remove knob.

Do Not Overtighten.

Item 1 2 3 4 5 6 7 8 9 10/10a 11 12 13	Qty. 2 1 1 1 1 1 1 1/1 1 1	Description Base Plate w/ 1 Hole Base Plate w/ 2 Holes 42" Lower Square Vertical Extrusion 42" Upper Square Vertical Extrusion 42" Upper Square Vertical Extrusion 42" Lower Square Vertical Extrusion 32" Upper Square Vertical Extrusion 42" Lower Square Vertical Extrusion 42" Upper Square Vertical Extrusion 42" Upper Square Vertical Extrusion 42" Upper Square Vertical Extrusion 42" Upper Square Vertical Extrusion 42" Lower Square Vertical Extrusion 42" Square Vertical Extrusion 41" Horizontal Extrusion 40.9826" Curved Extrusion 41" Stabilizing Extrusion	Steps: 1) Attach verti 2) Attach uppe 4) Connect sta 5) Attach horiz 6) Apply graph
		dicates location of BACKSIDE of unit.	

SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



www.classicexhibits.com


# Step 1

© 2012

## Page 1 of 3

# Order #XXXXX - Sacagawea VK-1237 - Attachments

#### Steps:




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

# Step 2

#### 866.652.2100




© 2012


## Page 2 of 3

Item	Qty	Description
19	4	38" Vertical Extrusion
20/20a	2/2	12" Horizontal Extrusion
21	2	25" Horizontal Extrusion

#### Steps

- 1) Attach horizontal extrusions [20 and 20a] between vertical extrusions [19], placing inserts between horizontals.
- 2) Attach curved horizontal extrusions [21] between vertical extrusions [19], placing insert between curved horizontals.
- 3) Place shelf on top of lip of extrusions.
- 4) Set counter top on assembled base.







WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

# Step 3



Page 3 of 3




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

## Graphics


Setup Hardware & Literature Pockets

Halogen Lights



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com



Level 4